


This system does not in the sense have a idle control valve ,

This system controls the idle speed by regulating the injection quantity in order to match the actual speed to the target speed calculated by the engine ECU.

- Coolant Temperature
- Air Conditioner Load
- Gear Position



- The target speed varies, depending on the ON/OFF state of the air conditioner and the coolant temperature.